



Lipo Meter And Balancer Manual

NO.3933

Lipo Meter w/Balancer: Simply connect Lipo battery charge connector to the Lipo Meter. It will detect each individual cell voltage of Lipo batteries within the pack (2-4 cells) and balance them down to the same level of the lowest cell voltage detected.

Features: Reverse protection, auto cut-off ($V < 2.5V$)

Working Voltage: 2-4 cells Lipo

Tolerance: $\pm 0.01V$

Max Balance Current: 210mA

Cut-off Voltage: 2.5V

