

## INSTRUCTIONS:

1. Press TACT SWITCH to choose the number of the blade: 2, 3 or 4-blade
2. Aim the SENSOR at the propellers of the airplane in the distance between 15~45 cm
3. Be sure that the source of the light is from the sunlight. If it comes from the fluorescent lamp, the number showing on the screen will be incorrect due to interference
4. The real value of the rpm is equal to what the number shown on the screen multiplies 10. The error of the value is about  $\pm 10$  rpm
5. Beware of the polarities when replace the LITHIUM BATTERY

